


# HITCASE




## QUICK START GUIDE

### CLOSING HITCASE



Press on the front of the case with your thumbs, below the respective latch, then press down on the latch to close. **“Squeeze and Pop”**.


### OPENING HITCASE



Undo latches and open your HITCASE **like a book**, camera side down to prevent any possible water or debris from getting on your iPhone


### USING RAILSLIDE

①



Align the Railslide with the rails on your HITCASE. Slide in until you feel resistance, then push again until it clicks.


②



Squeeze trigger on Railslide and apply pressure to HITCASE to remove.

### MAKING CALLS

For the best experience when making phone calls, pop the bottom latch of your Hitcase. Your iPhone will **NOT** be waterproof while the latch is open.



Make sure your HITCASE is free of water and debris before opening to remove your iPhone.

Go to [Hitcase.com](http://Hitcase.com) to:

- Find more tips on how to get the most out of your hitcase.
- Get warranty and support information.
- Check out the latest Railslide accessories and **download the VIDOMETER App**.



All Rights Reserved Hitcase 2012